

# ARCS Wide/Focus



user manual (EN)





# ARCS® WIDE SYSTEM ARCS® FOCUS SYSTEM USER MANUAL

VERSION 4.0

Document reference: ARCSWIFO\_UM\_EN\_4.0
Distribution date: December 15, 2021

© 2021 L-ACOUSTICS®. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means without the express written consent of the publisher.



#### SAFETY INSTRUCTIONS

- I. Read this manual
- 2. Follow all SAFETY INSTRUCTIONS as well as DANGER and OBLIGATION warnings
- 3. Never incorporate equipment or accessories not approved by L-ACOUSTICS®
- 4. Read all the related PRODUCT INFORMATION documents before exploiting the system

The product information document is included in the shipping carton of the related system component.

5. Inspect the system before any deployment.

Perform safety related checks and inspections before any deployment.

Perform preventive maintenance at least once a year.

Insufficient upkeep of the product can void the warranty.

If any safety issue is detected during inspection, do not use the product before performing corrective maintenance.

Check for issues. A rigging system part or fastener is missing or loose. A rigging system part exhibits: bends, breaks, broken parts, corrosion, cracks, cracks in welded joints, deformation, denting, wear, holes. A safety cue or label is missing.

6. Read the RIGGING MANUAL before installing the system

Use the rigging accessories described in the rigging manual and follow the associated procedures

7. Beware of sound levels

Do not stay within close proximity of loudspeakers in operation and consider wearing earplugs. Loudspeaker systems are capable of producing very high sound pressure levels (SPL) which can instantaneously lead to permanent hearing damage to performers, production crew and audience members. Hearing damage can also occur with prolonged exposure to sound: 8 h at 90 dB(A), 30 min at 110 dB(A), less than 4 min at 130 dB(A).

#### SYMBOLS

The following symbols are used in this document:



#### DANGER

This symbol indicates a potential risk of harm to an individual or damage to the product.

It can also notify the user about instructions that must be strictly followed to ensure safe installation or operation of the product.



#### **OBLIGATION**

This symbol notifies the user about instructions that must be strictly followed to ensure proper installation or operation of the product.



#### **INFORMATION**

This symbol notifies the user about complementary information or optional instructions.

# ARCS® WIDE SYSTEM ARCS® FOCUS SYSTEM

#### USER MANUAL

VERSION 4.0

#### CONTENTS

ARC	S® WIDE / FOCUS SYSTEM	5
ı	SYSTEM COMPONENTS	6
1.1	Loudspeaker enclosure	6
1.2	Powering and driving system	6
1.3	Loudspeaker cables	6
1.4	Rigging element	6
1.5	Software application	6
2	LOUDSPEAKER CONFIGURATIONS	8
2.1	Line source	8
	Standalone ARCS WIDE/FOCUS line source	8
2.2	Line source with low-frequency element	9
	ARCS WIDE/FOCUS line source + SB18m	9
2.3	Line source element	10
	Single ARCS WIDE/FOCUS enclosure	10
2.4	Line source with low-frequency element	11
	Single ARCS WIDE/FOCUS + SB18m	11
3	LOUDSPEAKER CONNECTION	12
3.1	Connectors	12
3.2	Connection to LA4 / LA4X	13
	Option A	13
	Option B	15
3.3	Connection to LA8	16
	Option A	16
	Option B	18
APPE	ENDIX A PRESET DESCRIPTION	20
	[ARCS_WIFO] and [ARCS_WIFO_FI]	20
	[SB18_60]	20
	[SB18_60_C]	20
APPE	ENDIX B RECOMMANDATION FOR SPEAKER CABLES	21
<u>APP</u> E	ENDIX C SPECIFICATIONS	22
	ARCS FOCUS	22
	ARCS WIDE	23
	SB18m	24



#### ARCS® WIDE / FOCUS SYSTEM

The ARCS® WIDE and ARCS® FOCUS systems are based on two constant curvature enclosures ensuring distinct directivity pattern and SPL capabilities. Intended for medium-throw applications in rental productions and fixed installations, these line sources deliver remarkable acoustic properties and unmatched versatility for applications including FOH L/R systems, central clusters, side-fill monitors, distributed systems and complementary fills.

The main systems components consist of the following:

- ARCS® WIDE (H x V: 30° x 90°) element, wide coverage, operating from 55 Hz to 20 kHz;
- ARCS® FOCUS (H x V:  $15^{\circ}$  x  $90^{\circ}$ ) element, focused energy, operating from 55 Hz to 20 kHz;
- SB18m low frequency extension, operating down to 32 Hz;
- LA4, LA4X or LA8 amplified controllers.

The ARCS® WIDE or ARCS® FOCUS line sources provide high SPL with perfect acoustic coupling, a solid LF performance and constant tonal balance over distance. Both systems can be deployed either as a horizontal array or as a vertical array.

In the coupling plane, the ARCS® WIDE and ARCS® FOCUS yield a razor-sharp directivity pattern, particularly valuable to sector audience fields while avoiding reflective surfaces. In the other plane, both systems provide a 90° smooth symmetric directivity pattern.

The ARCS $^{\circ}$  WIDE is suited to achieve an extensive coverage with few elements, offering a remarkably compact array preserving sightlines. The total coverage angle of an ARCS $^{\circ}$  WIDE line source is proportional to the number N of enclosures in the array, i.e. N x 30 $^{\circ}$ .

The ARCS $^{\circ}$  FOCUS line source focuses the same acoustic energy within half of the coverage angle, i.e. N x 15 $^{\circ}$ . The ARCS $^{\circ}$  FOCUS is therefore suited to achieve a narrower coverage, offering a higher SPL with a more extended throw than its sibling.

The ARCS® WIDE and ARCS® FOCUS can also be deployed in "WIFO" hybrid arrays for complex audience geometries. The dual directivity pattern and the various system configurations offered to the sound designer and system engineer allow a high level of creative freedom. Before installation, all these configurations can be acoustically and mechanically modeled with the SOUNDVISION 3D simulation software.

The amplified controllers offer an advanced and precise drive system for the ARCS® WIDE and ARCS® FOCUS enclosures. Both can be driven with the same preset. All L-ACOUSTICS amplified controllers feature the L-DRIVE, a thermal and over-excursion protection circuit.

Up to 253 LA8 amplified controllers can be connected together via the Ethernet-based L-NET protocol. The LA NETWORK MANAGER software allows online remote control and monitoring of all the connected units, via a user-friendly and intuitive graphic interface, and features the Array Morphing EQ. This exclusive tool allows the engineer to quickly adjust the tonal balance of the system to reach a reference curve or to ensure consistency of the sonic signature.

#### USER MANUAL

VERSION 4.0

#### 1 SYSTEM COMPONENTS

The system approach developed by L-ACOUSTICS® consists in offering a global solution that guarantees the highest and most predictable level of performance at any step of loudspeaker system deployment: modeling, installation, and operation. A complete L-ACOUSTICS® system includes enclosures, amplified controllers, cables, rigging system and software applications.

#### I.I Loudspeaker enclosure

ARCS® WIDE Full-range (55Hz - 20kHz), 2-way passive, constant curvature WST® line source, 90° x 30° ARCS® FOCUS Full-range (55Hz - 20kHz), 2-way passive, constant curvature WST® line source, 90° x 15°

SB18m High power subwoofer (down to 32Hz)



#### Loudspeaker system design

Sound design aspects are beyond the scope of this document. However, the various applications of the system will be based on the loudspeaker configurations presented in this document.

#### 1.2 Powering and driving system

LA4, LA4X or LA8 Amplified controllers with DSP, preset library and networking capabilities



#### **Operating instructions**

Refer to the LA4, LA4X, LA8 or LA-RAK user manuals.

#### 1.3 Loudspeaker cables

DO cables (DO.7, DO10, DO25) 8-point PA-COM® loudspeaker cables (4 mm² section).

Respective lengths of 0.7 m/2.3 ft, 10 m/32.8 ft, and 25 m/82 ft.

DOSUB-LA8 Breakout cable for four passive enclosures.

8-point PA-COM® to  $4 \times 2$ -point SpeakON® (4 mm<sup>2</sup> section).

SP cables (SP.7, SP5, SP10, SP25) 4-point SpeakON® loudspeaker cables (4 mm² section).

Respective lengths of 0.7 m/2.3 ft, 5 m/16.4 ft, 10 m/32.8 ft and 25 m/82 ft.

SP-YI Breakout cable for two passive enclosures.

4-point SpeakON® to  $2 \times 2$ -point SpeakON® (2.5 mm<sup>2</sup> section).

Provided with CC4FP adapter.



Information about the connection of the enclosures to the LA amplifiers is given in this document.

Refer to the **LA4**, **LA4X**, **LA8** or **LA-RAK** user manuals for detailed instructions about the whole cabling scheme, including modulation cables and network.

#### 1.4 Rigging element



Rigging elements or procedures are not presented in this document.

Refer to the ARCS® WIDE/FOCUS rigging manual.

#### 1.5 Software application

SOUNDVISION Proprietary acoustical and mechanical 3D modeling software.

LA NETWORK MANAGER Remote control and monitoring of amplified controllers



#### Using L-ACOUSTICS® software

Refer to the SOUNDVISION user manual and the LA NETWORK MANAGER tutorial.







SBI



ARCS® WIDE/FOCUS system components (excluding rigging elements and modulation cables)

#### **USER MANUAL**

VERSION 4.0


#### 2 LOUDSPEAKER CONFIGURATIONS

#### 2.1 Line source

Deployed as a standalone line source, an ARCS WIDE/FOCUS system operates over the nominal bandwidth of the ARCS WIDE/FOCUS enclosure.

The [ARCS\_WIFO] preset allows for a reference frequency response in medium throw applications.

This configuration is driven by the LA4, LA4X or LA8 amplified controller.






#### 2.2 Line source with low-frequency element

In this configuration – an ARCS® WIDE/FOCUS line source deployed with SB18m subwoofers – the system bandwidth is extended in the low end.

The [ARCS WIFO] preset allows for a reference frequency response in medium throw applications.

The [SB18\_60] preset provides the subwoofer enclosures with an upper frequency limit at 60 Hz for an optimal frequency coupling with the ARCS® WIDE/FOCUS line source.

This configuration is driven by the LA4, LA4X or LA8 amplified controllers.



#### USER MANUAL


VERSION 4.0

#### 2.3 Line source element

In this configuration – a single ARCS $^{\circ}$  WIDE/FOCUS enclosure without complementary subwoofers – the system operates over the nominal bandwidth of the enclosure.

The [ARCS\_WIFO\_FI] preset allows for a reference frequency response in short throw applications.

This configuration is driven by the LA4, LA4X or LA8 amplified controller.






#### 2.4 Line source with low-frequency element

In this configuration – a single ARCS $^{\otimes}$  WIDE/FOCUS enclosure deployed with an SB18m subwoofer – the system bandwidth is extended in the low end.

The [ARCS\_WIFO\_FI] preset allows for a reference frequency response in short throw applications.

The [SB18\_60] preset provides the subwoofer enclosures with an upper frequency limit at 60 Hz for an optimal frequency coupling with the ARCS® WIDE/FOCUS element.

This configuration is driven by the LA4, LA4X or LA8 amplified controllers.




#### USER MANUAL

VERSION 4.0

#### 3 LOUDSPEAKER CONNECTION

#### 3.1 Connectors





#### Internal pinout for L-ACOUSTICS® ARCS WIDE/FOCUS and SB18m

SpeakON® points	1+	1 -	2 +	2 -
Transducer connectors	+	-	Not used	Not used



#### 3.2 Connection to LA4 / LA4X



#### Maximum number of enclosures per LA4 / LA4X

One ARCS® WIDE/FOCUS or one SB18m can be connected to each output channel on the LA4 / LA4X. Therefore, a single LA4 / LA4X amplified controller can drive up to:

- 4 × ARCS® WIDE/FOCUS or
- 4 × SB I 8m or
- 3 × ARCS® WIDE/FOCUS and I × SB18m.
- 0


#### **Cardioid configuration**

Connect the reversed subwoofer(s) to OUT I to use the cardioid preset.

i Impedance load 8  $\Omega$  for 1 enclosure.


#### **Option A**

▶ Use **SP cables** (SP.7, SP5, SP10 or SP25) to connect first enclosures to the four LA4 / LA4X output channels.




LA4 / LA4X option A maximum configuration with ARCS® WIDE/FOCUS

VERSION 4.0



LA4 / LA4X option A maximum configuration with ARCS $^{\circ}$  WIDE/FOCUS + SB18m




LA4 / LA4X option A maximum configuration with SB18m




#### **Option B**


- ► Connect an SP cable (SP.7, SP5, SP10 or SP25) to the OUT1/OUT2 and OUT3/OUT4 connectors of the LA4 / LA4X.
- ▶ Use a **CC4FP adapter** to connect an **SP-YI cable** and separate the two output channels.



LA4 / LA4X option B maximum configuration with ARCS® WIDE/FOCUS



LA4 / LA4X option B maximum configuration with ARCS® WIDE/FOCUS + SB18m



LA4 / LA4X option B maximum configuration with SB18m

#### **USER MANUAL**

VERSION 4.0

#### 3.3 Connection to LA8



#### Maximum number of enclosures per LA8

Two ARCS WIDE/FOCUS or two SB18m can be connected in parallel to each output channel on the LA8. Therefore, a single LA8 amplified controller can drive up to:

- 8 × ARCS® WIDE/FOCUS or
- 8 × SB I 8m or
- 4 × ARCS® WIDE/FOCUS and 4 × SB18m.
- 0

#### **Cardioid configuration**

Connect the reversed subwoofer(s) to OUT I to use the cardioid preset.


i

#### Impedance load

8  $\Omega$  for 1 enclosure, 4  $\Omega$  for 2 enclosures.

#### **Option A**

- ► Connect a **DO cable** (DO.7, DO10 or DO25) to the LA8 PA-COM® connector
- ▶ Use the **DOSUB-LA8** to separate the four output channels.
- ▶ If necessary, use **SP cables** to connect additional similar enclosures in parallel with the first ones.




LA8 option A maximum configuration with ARCS® WIDE/FOCUS




#### Corresponding DOSUB-LA8 SpeakON® points and LA8 output channels:

SPK1 = OUT I SPK3 = OUT 3 SPK2 = OUT 2 SPK4 = OUT 4





LA8 option A with ARCS® WIDE/FOCUS + SB18m




# ARCS® WIDE SYSTEM ARCS® FOCUS SYSTEM

#### **USER MANUAL**


VERSION 4.0

#### Option B

- ► Connect an **SP** cable (SP.7, SP5, SP10 or SP25) to the OUT1/OUT2 and OUT3/OUT4 LA8 SpeakON® connectors.
- ▶ Use a **CC4FP adapter** to connect an **SP-YI** cable and separate the two output channels.
- ▶ If necessary, use **SP cables** to connect additional similar enclosures in parallel with the first ones.




LA8 option B maximum configuration with ARCS® WIDE/FOCUS



LA8 option B with ARCS® WIDE/FOCUS + SB18m





LA8 option A maximum configuration with SB18m

#### **USER MANUAL**

VERSION 4.0

#### APPENDIX A PRESET DESCRIPTION

#### [ARCS WIFO] and [ARCS WIFO FI]

The [ARCS\_WIFO] preset allows for a reference frequency response in medium throw applications.

The [ARCS WIFO FI] preset allows for a reference frequency response in short throw applications.

Lauden selven elemente	Amenifican automate	Channela		Defa	ult paran	neters	
Loudspeaker elements	Amplifier outputs	Channels	Routing	Gain	Delay	Polarity	Mute
ARCS WIDE/FOCUS	OUT I	PA	IN A	0 dB	0 ms	+	ON
ARCS WIDE/FOCUS	OUT 2	PA	IN A	0 dB	0 ms	+	ON
ARCS WIDE/FOCUS	OUT 3	PA	IN B	0 dB	0 ms	+	ON
ARCS WIDE/FOCUS	OUT 4	PA	IN B	0 dB	0 ms	+	ON

#### [SB18 60]

The [SB18\_60] preset provides the subwoofer enclosures with an upper frequency limit at 60 Hz.

Lauden selven elemente	A!:C	Champala	Default parameters				
Loudspeaker elements	Amplifier outputs	Channels	Routing	Gain	Delay	Polarity	Mute
SB18	OUT I	SB	IN A	0 dB	0 ms	+	ON
SB18	OUT 2	SB	IN A	0 dB	0 ms	+	ON
SB18	OUT 3	SB	IN B	0 dB	0 ms	+	ON
SB18	OUT 4	SB	IN B	0 dB	0 ms	+	ON

#### [SB18 60 C]

The [SB18\_60\_C] preset provides the subwoofer enclosures with an upper frequency limit at 60 Hz.

It features optimized delay settings for SB18 arrays in cardioid configuration.

Lauden a dem a la manta	Ameniii am autouta	Champala	Default parameters				
Loudspeaker elements	Amplifier outputs	Channels	Routing	Gain	Delay	Polarity	Mute
Reversed SB18	OUT I	SR	IN A		0 ms	+	ON
SB18	OUT 2	SB		0 dB			ON
SB18	OUT 3	SB					ON
SB18	OUT 4	SB					ON



#### APPENDIX B RECOMMANDATION FOR SPEAKER CABLES



#### Cable quality and resistance

Only use high-quality fully insulated speaker cables made of stranded copper wire.

Use cables of gauge offering low resistance per unit length and keep the cables as short as possible.

The following table provides the recommended maximum length depending on the cable cross-section and on the impedance load connected to the amplifier.

			Recommended maximum length					
Cable cross-section			8 Ω	8 Ω load 4 Ω lo		load	2.7 Ω load	
mm²	SWG	AWG	m	ft	m	ft	m	ft
2.5	15	13	30	100	15	50	10	33
4	13	П	50	160	25	80	17	53
6	П	9	74	240	37	120	25	80
10	9	7	120	390	60	195	40	130

#### USER MANUAL

VERSION 4.0

#### APPENDIX C SPECIFICATIONS

#### **ARCS FOCUS**

Description	2-way passive enclosure, amplified by LA4 / LA4X / LA8 / LA12X					
Usable bandwidth (-10 dB)	55 Hz - 20 kHz ([ARCS_WIFO] preset)					
Maximum SPL <sup>1</sup>	139 dB ([ARCS_WIFO] preset)					
Coverage angle (-6 dB)	15° × 90°					
	LF: I × I2", weather-resistant, bass-reflex.					
Transducers	HF: I × 3", diaphragm compression driver, DOSC® waveguide.					
Nominal impedance	8Ω					
RMS power handling	450 W					
Connectors	IN: I × 4-point SpeakOn®					
Rigging components	LINK: 4-point SpeakOn®  Rigging rails and WIFORIG coupling bars.					
00 0 1	444 mm / 17.5 in					
Dimensions  Weight (net)	9 mm / 29.9 in  252 mm / 9.9 in  365 mm / 14.4 in  38 kg / 84 lb					
Cabinet:	: अठ kg / ठम ।। Baltic birch plywood.					
Finish:	Dark Grey brown (Pantone 426C)					
Physical data	Pure white (RAL 9010®) Custom RAL code on special order					
Front:	Steel grill with anti-corrosion coating, Airnet® fabric					
Protection R						
Rigging comp						

Peak level measured at 1 m under free field conditions using pink noise with crest factor 4 (preset specified in brackets).



### **ARCS WIDE**

WALLE THE STATE OF								
Description		2-way passive enclosure, amplified by LA4 / LA4X / LA8 / LA12X						
Usable bandwid	lth (-10 dB)	55 Hz - 20 kHz ([ARCS_WIFO] preset)						
Maximum SPL <sup>1</sup>		I37 dB ([ARCS_WIFO] preset)						
Coverage angle	(-6 dB)	30° × 90°						
Transducers		LF I $\times$ I2", weather-resistant, bass-reflex.						
Transducers		HF I $\times$ 3", diaphragm compression driver, DOSC® waveguide.						
Nominal impeda	ance	8 Ω						
RMS power han	dling	450 W						
Connectors		IN: I × 4-point SpeakOn <sup>®</sup> LINK: 4-point SpeakOn <sup>®</sup>						
Rigging compon	ents	Rigging rails and WIFORIG coupling bars.						
Dimensions	Weight (net	365 mm / 14.4 in 2): 36 kg / 79 lb						
	Cabinet:	Baltic birch plywood.						
	Finish:	Dark Grey brown (Pantone 426C)						
Dhyelas Jaka		Pure white (RAL 9010®)						
Physical data		Custom RAL code on special order						
	Front:	Steel grill with anti-corrosion coating, Airnet® fabric						
1	Protection F	*						
	Rigging com	nponents: High strength steel with anti-corrosion coating						
11. 11 1 1	de la constantina Caldana dicina conicación a circonich constituente factor de la constituente de la constit							

Peak level measured at 1 m under free field conditions using pink noise with crest factor 4 (preset specified in brackets).

# ARCS® WIDE SYSTEM ARCS® FOCUS SYSTEM

#### USER MANUAL

VERSION 4.0

#### <u>SB18m</u>

		C b (					
Description		Subwoofer enclosure, amplified by LA4 / LA4X / LA8 / LA12X					
Low frequency lin	nit (-10 d <b>B</b> )	32 Hz ([SB18_100] preset)					
Maximum SPL <sup>1</sup>		138 dB ([SB18_100] preset)					
RMS power hand	ling	700 W					
Transducers		$I \times I8$ " weather-resistant, bass-re	eflex				
Nominal impedan	ice	8 Ω					
Connectors		IN: I × 4-point SpeakON®	LINK: I × 4-point SpeakON®				
Rigging componer	nts	Integrated pole-mount socket Captive coupling bars Handles integrated into the cabine	Integrated pole-mount socket				
Dimensions  Dimensions		759 mm / 29.9 in  BOTTOM	717 mm / 28.2 in				
	Weight (net):	62 kg / 137 lb					
	Cabinet:	Baltic birch plywood					
Physical data	Finish:	Dark Grey brown (Pantone Pure white (RAL 9010®) Custom RAL code on spec	,				
	Front:	Steel grill with anti-corrosic	on coating				
	Rigging components:	Steel with anti-corrosion conditions using pink noise with crest factor 4					

Peak level measured at 1 m under half-space conditions using pink noise with crest factor 4 (preset specified in brackets).



#### **L-Acoustics**

13 rue Levacher Cintrat - 91460 Marcoussis - France +33 1 69 63 69 63 - info@l-acoustics.com www.l-acoustics.com

